

KILLER CHROME KIT

APPLICATION GUIDE

Killer Chrome Kit (KC-KCH-Kit) contents:

1 Killer Chrome KC-KC101
1 Stylin Basecoat (Jet Black) KC-ASB13
1 Lightning Clear KC-ALC-770
1 Polishing Cloth

***NOTE:** If you already have a SMOOTH black surface you can skip to Step 2 of the application process.*

Step 1. - Apply the Killer Cans "Stylin Basecoat (Jet Black) KC-ASB13" over a prepped and primed surface.

Step 2. - Using the Killer Cans "Lightning Clear KC-ALC-770" you should now topcoat the black basecoat to provide you with a High Gloss surface and insure the best results with Killer Chrome.

Step 3. - These parts should now be allowed to FULLY cure for 24 hours.

Step 4. - You are now ready to apply the Killer Chrome over the previously prepared piece. Begin by applying light "**DUST**" coats. **Do NOT SPRAY WET LIKE A SPRAY PAINT!** This is a true metal deposition and requires a light, **EVEN**, application.

Step 5. - Continue to apply these "**DUST**" coats until you have achieved a uniform coverage and allow it to dry for a few minutes before proceeding.

Step 6. - You will now use the polishing cloth (included in Killer Chrome Kit) to remove ANY excess material overspray or dust.

Step 7. - After waiting at least 15 minutes for all of the remaining solvents to fully evaporate you are ready to apply the protective topcoat "Lightning Clear KC-ALC-770".

Step 8. - Spray 1-2 coats evenly over the Killer Chrome to give it long lasting durability and an incredible amount of depth.

Step 9. – ****OPTIONAL**** - To achieve an automotive grade finish and durability you can next apply Alsa's unique (2K) clearcoat "Speed Clear KC-SC1230" (sold separately). Ensure "Lightning Clear KC-ALC-770" is fully cured then spray 1-2 coats evenly.

WARNING: "**Speed Clear KC-SC1230**" is for professional use only and requires the use of a NIOSH approved mask in a well ventilated area.

*****DON 'T FORGET TO TRY COMBINING THE LOOK OF KILLER CHROME WITH ANY OF OUR OTHER KILLER CANS FOR TRUELY OUTRAGEOUS RESULTS.**