



## Application Guide

- Step 1.** Prepare and prime the surface as you would any normal paint job.
- Step 2.** Apply 2 wet coats to ensure uniform coverage.
- Step 3.** Let flash off before applying your final clear or taping off graphics.
- Step 4.** Topcoat with a poly-urethane clearcoat as you would with any other paint job.

**NOTE:** Stylin Basecoats need to be reduced with Medium Reducer at a ratio of 1:1. This is available by calling us directly for \$13.12/quart.

## Frequently Asked Questions

**Q. Are there any special preparations needed to use Alsa's Stylin Basecoats?**

**A.** No, with Stylin Basecoats there is no special prep needed. Simply prep & prime the surface as you would any other paintjob. Then apply 2 coats of Stylin Basecoat, followed by our Candy Concentrates or final clearcoat.

**Q. How long do Stylin Basecoats take to dry?**

**A.** Stylin Bases will air-dry within 5 min. to the touch however we recommend waiting at least 30.